



15 N Argonne Rd Spokane, WA 99212
877-921-1531
www.ultimateflap.com
Made in USA

UltimateFlap UF1007/UF1008 Installation Instructions

UF1007/UF1008 Hardware Kit	
6	#12 x 1 ¼" SS Screws
6	¼" SS Fender Washers
4	¼" x 20 x 1 SS Bolts
4	¼" x 20 SS Locknuts
4	¼" SS Flatwashers

NOTE: *UltimateFlap UF1007/UF1008 Dually Mud Flaps are designed for use on trucks with standard pickup beds. Installation procedures may be different for cab-chassis, service body, flat bed, and/or motor home applications. Additional hardware beyond the supplied kit may be needed in these cases.*

1. Review Universal Front & Rear Mud Flap Installation Instruction sheet included with UltimateFlap Mud Flap kit for suggested basic installation
2. Follow Universal Rear Install Instructions, with noted exceptions:
 - a. Position UltimateFlap on vehicle for best protection from stones and Debris. **MINIMUM 7" OF GROUND CLEARANCE**
 - b. Start at the top of the UltimateFlap and drill 9/64" hole through the mud flap and fender lip – secure with screw and large flat washer.
 - c. Align the UltimateFlap so it is straight (use a level), and repeat step b. Drill two more holes, install screws, and washers.
 - d. ****Drill ¼ inch hole through inside corner of flap and inner dually fender liner.**** Insert ¼ inch bolt, small washers & nuts, and tighten.
 - e. Repeat process with next flap